

DECALCIFYING PROCESS

WITH WATER PUMP



for TYENT Europe
Water Ionizers

Attention: In order to avoid damages, please read the whole instructions carefully first.

Contents of packing:

Water pump, adapter (is tucked into the pump), container for the pump, 2 bags of decalcifying agent (citric acid), **connecting hose (UCE-9000 Turbo only)**.

Warning:

- Avoid eye contact.
- If the eyes have had contact with the decalcification solution, thoroughly rinse with water.
- Only use citric acid for decalcification.
- Keep the decalcification process out of reach of children.
- The decalcification solution is not drinkable.

Place the container in the sink. Place the pump in the container and press the pump down slightly so that the suction cups firmly adhere on the ground.

MMP/HI IONIZER:

Insert the acidic drain hose 2cm wide on the adapter to the pump.

UCE IONIZER:

Plug the widened end of the supplied hose firmly on the upper tap at the water dispenser. Connect the other end with the pump. Please see also the photo.

Fill the container with lukewarm water (35°C max.). Plugin the pump so it may pump water into the ionizer until warm water flows out of the **flexible hose (MMP/HI Ionizer)** / **lower faucet of the water dispenser (UCE Ionizer)**. Turn off the pump. Use this procedure to remove the cold water from the ionizer.



Attention: In order to avoid damages, please read the whole instructions carefully first.



Refill the container with lukewarm water and dissolve one bag of citirc acid in it. Turn the pump back on. Position the **flexible hose (MMP/ HI Ionizer)** / **lower faucet of the water dispenser (UCE Ionizer)** so the decalcifying solution flows into the container. Run this cycle for about 30 - 45 minutes.

Attention:

In order to avoid any damage to the pump, it must always be immersed in water and should never run dry! If the water level lowers, please refill lukewarm water and possibly some descaler.

In case a large quantity of scale has collected in the container, please prepare a new decalcification solution and repeat the process.

After the decalcification process has been completed, rinse the pump with clear water in order to avoid that any residues remain in the pump. Unplug. Draw the adapter with the hose out of the pump.

HI IONIZER
(same function as MMP)



After decalcification rinse the ionizer thoroughly for 2-3 minutes at the level „H₂O“/Neutral. Repeat the decalcification process every three months or as required.

In case of further questions please ask your specialised dealer.





www.tyent-europe.com

Baeck GmbH & Co. KG

Langenharmer Weg 223-225 · D-22844 Norderstedt · Germany

Telefon: +49 (0) 40-521 706-0 · Fax: +49 (0) 40-525 30 41

Web: www.tyent-europe.com · E-Mail: info@tyent-europe.com

08/2015